

#### General Description

The MAX3983 evaluation kit (EV Kit) is an assembled demonstration board that provides electrical evaluation of the MAX3983 Quad Copper Cable Signal Conditioner. The EV Kit also includes a calibration strip for accurate measurements.

#### **Component List**

DESIGNATION	I QTY	DESCRIPTION	
C1-C32, C35- C44	42	0.01μF ±5% ceramic capacitors (0402)	
C33	1	33μF tantalum capacitor	
C34, C45, C46 C49	4	0.1μF ±5% ceramic capacitors (0402)	
C47, C48, C50 C51	4	Not Installed	
J1-J18	18	SMA connectors, edge mount	
JP1, JP2, JP8, JP9, JP12	5	2-pin headers, 0.1in centers	
JP3	1	3-pin header, 0.1in centers	
JP5	1	3-pin + 1-pin header, 0.1in centers	
JP10, JP11	2	Not Installed	
L1	1	4.7μH Inductor Coilcraft DS1608C-472	
P1	1	4x IB Connector FCI 58369- 111120 or 58369-112110	
R1-R8	8	4.7kΩ ±5% resistors (0402)	
R10 - R18	9	Not Installed	
TP1-TP11	11	Test points Digi-Key 5000K-ND	
U1	1	MAX3983UGK 68-QFN*	
U2	1	OR Gate Fairchild NC7S32P5X SC70	
None		MAX3983 evaluation circuit board, rev A	
None		MAX3983 data sheet	

\*Note: U1 has an exposed pad which requires it to be solder attached to the circuit board to insure proper functionality of the part.

### \_\_\_\_\_ Features

- ♦ Fully Assembled and Tested
- ♦ Easy Selection of Operating Modes
- ♦ Equipped with a 4X InfiniBand Cable Connector

#### **Ordering Information**

PART	TEMP. RANGE	IC PACKAGE
MAX3983EVKIT	0°C to +85°C	68 QFN

#### Component Suppliers

SUPPLIER	PHONE	FAX
AVX	843-448-9411	843-448-1943
Coilcraft	847-639-6400	847-639-1469
Digi-Key	218-681-6674	218-681-3380
Murata	770-436-1300	770-436-3030

**Note:** Please indicate that you are using the MAX3983 when ordering from these suppliers.

#### Quick Start

- 1) Connect a +3.3V supply to the 3.3V terminal and ground to the GND terminal.
- Disable system loopback by installing the LOOPBACK shunt at jumper JP9.
- Remove shunts at jumpers JP3 and JP5 to enable TX and RX.
- Install shunt at jumper JP2 to V<sub>CC</sub> to provide +3.3V to the SD pullup resistors.
- Apply 2.5Gbps to 3.2Gbps data to TX\_IN[1:4] (J9 - J16).
- Apply 2.5Gbps to 3.2Gbps data to RX\_IN[1:4] through a 1m to 5m InfiniBand 4X cable assembly.
- Connect data outputs RX\_OUT[1:4] to a 50 ohm-terminated oscilloscope to monitor RX\_IN[1:4] data, and/or connect TX\_OUT[1:4] to a 50 ohm-terminated oscilloscope through a 1m to 15m InfiniBand 4X cable assembly to monitor TX\_IN[1:4] data.
- Adjust TX pre-emphasis with jumpers JP1 and JP12, and adjust RX pre-emphasis with JP8 (see *Jumper Descriptions*).

#### **Jumper Descriptions**

NAME	TYPE	SHUNT POSITION	DESCRIPTION
TX_PE1 2-pin header	OPEN	Enables most-significant bit of TX pre-emphasis control	
	SHUNT (GND)	Disables most-significant bit of TX pre-emphasis control	
TX_PE0 (JP12) 2-pin header	2 nin hoador	OPEN	Enables least-significant bit of TX pre-emphasis control
	2-piii fieadei	SHUNT (GND)	Disables least-significant bit of TX pre-emphasis control
RX_PE (JP8) 2-pin header	2 nin hoador	OPEN	Sets RX pre-emphasis to 6dB
	2-pin neader	SHUNT (GND)	Sets RX pre-emphasis to 3dB
LOOPBACK	LOOPBACK On in head on	OPEN	Enables loopback from TX_IN[1:4] to RX_OUT[1:4]
(JP9) 2-pin header	SHUNT (GND)	Disables loopback	
PULLUP (JP2) 2-pin header	2-pin header	OPEN	Allows external voltage (3.0V to 5.5V) applied at V <sub>PULLUP</sub> pin as SD resistor pullup voltage
		SHUNT (V <sub>CC</sub> )	Sets Vcc as the SD resistor pullup voltage
TX_ENABLE (JP3) 3-pin header		OPEN	Enables the TX section of the MAX3983
	3-pin header	TX_AUTO_EN	Enables auto-detection in the TX section, when EV board is set up in the Auto-Detect configuration. See Auto-Detect Configuration in Detailed Description.
	TX_DISABLE	Disables the TX section of the MAX3983	
RX_ENABLE 3-pin + (JP5) 1-pin header	OPEN O	Enables the RX section of the MAX3983	
	3-nin +	RX_AUTO_EN	Enables auto-detection in the RX section when EV board is set up in the Auto-Detect configuration. See Auto-Detect Configuration in Detailed Description.
		RX_DISABLE O	Disables the RX section of the MAX3983
		000	Sets RX_ENABLE high whenever LOOPBACK or all of RX_SD[1:4] are high when EV board is set up in the Auto-Detect configuration. See <i>Auto-Detect Configuration</i> in <i>Detailed Description</i> .

#### \_Detailed Description

#### **Auto-Detect Configuration**

The MAX3983 Evaluation Kit is shipped with each signal detect (SD) separated. In order for the MAX3983 to automatically detect an incoming signal and enable the corresponding output, these SD outputs need to be connected together.

To configure the board for auto-detection on the RX side, solder four  $0\Omega$  0402 resistors in R14 - R17 and remove R6, R7, and R8. Jumper JP5 then enables RX auto-detect (see *Jumper Descriptions*).

To configure the board for auto-detection on the TX side, solder four  $0\Omega$  0402 resistors in R10 - R13 and remove R2, R3, and R4. Jumper JP3 then enables TX auto-detect (see *Jumper Descriptions*).

#### **Embedded Stripline**

The MAX3983 Evaluation Kit has approximately 2.5 inches of 4mil-wide FR4 stripline on the cable side inputs and outputs. This provides 2dB of loss at 3GHz, which slows the output transition times of the MAX3983 to approximately 60ps.

If slower transition times are desired, the MAX3983 Evaluation Kit provides a connection for 0402 capacitors across the TX outputs. To achieve about 100ps (20%-80%) edges, solder 1.5pF capacitors for C47, C48, C50, and C51.

2\_\_\_\_\_\_M/XI/M




Figure 1. MAX3983 EV Kit Schematic




Figure 2. MAX3983 EV Kit Component Placement Guide – Component Side




Figure 3. MAX3983 EV Kit PC Board Layout – Component Side (Signal), Layer 1




Figure 4. MAX3983 EV Kit PC Board Layout – Ground Plane, Layer 2

6\_\_\_\_\_\_M/XI/M




Figure 5. MAX3983 EV Kit PC Board Layout – Signal, Layer 3




Figure 6. MAX3983 EV Kit PC Board Layout – Ground Plane, Layer 4

N/IXL/N \_\_\_\_\_\_ /N/AXI/N




Figure 7. MAX3983 EV Kit PC Board Layout – Power Plane, Layer 5




Figure 8. MAX3983 EV Kit PC Board Layout - Bottom (Signal), Layer 6

Maxim makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Maxim assume any liability arising out of the application or use of any product or circuit and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters can and do vary in different applications. All operation parameters, including "typicals" must be validated for each customer application by customer's technical experts. Maxim products are not designed, intended or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Maxim product could create a situation where personal injury or death may occur.