


### NPN Silicon RF Transistor

- For low noise, high-gain broadband amplifiers at collector currents from 1mA to 20mA
- $f_T = 8\text{GHz}$   
 $F = 1.2\text{dB}$  at 900MHz



**ESD: Electrostatic discharge sensitive device, observe handling precaution!**

| Type     | Marking | Ordering Code | Pin Configuration |       |       | Package |
|----------|---------|---------------|-------------------|-------|-------|---------|
| BFR 182W | RGs     | Q62702-F1492  | 1 = B             | 2 = E | 3 = C | SOT-323 |

### Maximum Ratings

| Parameter  | Symbol    | Values         | Unit |
|--|-----------|----------------|------|
| Collector-emitter voltage                          | $V_{CEO}$ | 12             | V    |
| Collector-emitter voltage                          | $V_{CES}$ | 20             |      |
| Collector-base voltage                             | $V_{CBO}$ | 20             |      |
| Emitter-base voltage                               | $V_{EBO}$ | 2              |      |
| Collector current                                  | $I_C$     | 35             | mA   |
| Base current                                       | $I_B$     | 4              |      |
| Total power dissipation<br>$T_S \leq 90\text{ °C}$ | $P_{tot}$ | 250            | mW   |
| Junction temperature                               | $T_j$     | 150            | °C   |
| Ambient temperature                                | $T_A$     | - 65 ... + 150 |      |
| Storage temperature                                | $T_{stg}$ | - 65 ... + 150 |      |

### Thermal Resistance

|  |            |            |     |
|--|------------|------------|-----|
| Junction - soldering point <sup>1)</sup> | $R_{thJS}$ | $\leq 240$ | K/W |
|--|------------|------------|-----|

1)  $T_S$  is measured on the collector lead at the soldering point to the pcb.

**Electrical Characteristics** at  $T_A = 25^\circ\text{C}$ , unless otherwise specified.

| Parameter   | Symbol        | Values |      |      | Unit          |
|---|---------------|--------|------|------|---------------|
|   |               | min.   | typ. | max. |               |
| <b>DC Characteristics</b>   |               |        |      |      |               |
| Collector-emitter breakdown voltage<br>$I_C = 1 \text{ mA}, I_B = 0$    | $V_{(BR)CEO}$ | 12     | -    | -    | V             |
| Collector-emitter cutoff current<br>$V_{CE} = 20 \text{ V}, V_{BE} = 0$ | $I_{CES}$     | -      | -    | 100  | $\mu\text{A}$ |
| Collector-base cutoff current<br>$V_{CB} = 10 \text{ V}, I_E = 0$       | $I_{CBO}$     | -      | -    | 100  | nA            |
| Emitter-base cutoff current<br>$V_{EB} = 1 \text{ V}, I_C = 0$          | $I_{EBO}$     | -      | -    | 1    | $\mu\text{A}$ |
| DC current gain<br>$I_C = 10 \text{ mA}, V_{CE} = 8 \text{ V}$          | $h_{FE}$      | 50     | 100  | 200  | -             |

**Electrical Characteristics** at  $T_A = 25^\circ\text{C}$ , unless otherwise specified.

| Parameter   | Symbol        | Values |            |      | Unit |
|---|---------------|--------|------------|------|------|
|   |               | min.   | typ.       | max. |      |
| <b>AC Characteristics</b>   |               |        |            |      |      |
| Transition frequency<br>$I_C = 15 \text{ mA}, V_{CE} = 8 \text{ V}, f = 500 \text{ MHz}$  | $f_T$         | 6      | 8          | -    | GHz  |
| Collector-base capacitance<br>$V_{CB} = 10 \text{ V}, f = 1 \text{ MHz}$  | $C_{cb}$      | -      | 0.4        | 0.65 | pF   |
| Collector-emitter capacitance<br>$V_{CE} = 10 \text{ V}, f = 1 \text{ MHz}$   | $C_{ce}$      | -      | 0.24       | -    |      |
| Emitter-base capacitance<br>$V_{EB} = 0.5 \text{ V}, f = 1 \text{ MHz}$   | $C_{eb}$      | -      | 0.6        | -    |      |
| Noise figure<br>$I_C = 3 \text{ mA}, V_{CE} = 8 \text{ V}, Z_S = Z_{Sopt}$<br>$f = 900 \text{ MHz}$<br>$f = 1.8 \text{ GHz}$            | $F$           | -      | 1.2<br>1.9 | -    | dB   |
| Power gain <sup>1)</sup><br>$I_C = 10 \text{ mA}, V_{CE} = 8 \text{ V}, f = 900 \text{ MHz}$<br>$Z_S = Z_{Sopt}, Z_L = Z_{Lopt}$        | $G_{ms}$      | -      | 19         | -    |      |
| Power gain <sup>2)</sup><br>$I_C = 10 \text{ mA}, V_{CE} = 8 \text{ V}, f = 1.8 \text{ GHz}$<br>$Z_S = Z_{Sopt}, Z_L = Z_{Lopt}$        | $G_{ma}$      | -      | 12.5       | -    |      |
| Transducer gain<br>$I_C = 10 \text{ mA}, V_{CE} = 8 \text{ V}, Z_S = Z_L = 50 \Omega$<br>$f = 900 \text{ MHz}$<br>$f = 1.8 \text{ GHz}$ | $ S_{21e} ^2$ | -      | 15<br>9.5  | -    |      |

1)  $G_{ms} = |S_{21}/S_{12}|$

2)  $G_{ma} = |S_{21}/S_{12}| (k - (k^2 - 1)^{1/2})$

### SPICE Parameters (Gummel-Poon Model, Berkeley-SPICE 2G.6 Syntax) :

#### Transistor Chip Data

|       |         |          |       |          |          |        |          |          |
|-------|---------|----------|-------|----------|----------|--------|----------|----------|
| IS =  | 4.8499  | fA       | BF =  | 84.113   | -        | NF =   | 0.56639  | -        |
| VAF = | 21.742  | V        | IKF = | 0.14414  | A        | ISE =  | 8.4254   | fA       |
| NE =  | 0.91624 | -        | BR =  | 10.004   | -        | NR =   | 0.54818  | -        |
| VAR = | 2.2595  | V        | IKR = | 0.039478 | A        | ISC =  | 5.9438   | fA       |
| NC =  | 0.5641  | -        | RB =  | 2.8263   | $\Omega$ | IRB =  | 0.071955 | mA       |
| RBM = | 3.4217  | $\Omega$ | RE =  | 2.1858   | $\Omega$ | RC =   | 1.8159   | $\Omega$ |
| CJE = | 8.8619  | fF       | VJE = | 1.0378   | V        | MJE =  | 0.40796  | -        |
| TF =  | 22.72   | ps       | XTF = | 0.43147  | -        | VTF =  | 0.34608  | V        |
| ITF = | 6.5523  | mA       | PTF = | 0        | deg      | CJC =  | 490.25   | fF       |
| VJC = | 1.0132  | V        | MJC = | 0.31068  | -        | XCJC = | 0.19281  | -        |
| TR =  | 1.7541  | ns       | CJS = | 0        | fF       | VJS =  | 0.75     | V        |
| MJS = | 0       | -        | XTB = | 0        | -        | EG =   | 1.11     | eV       |
| XTI = | 3       | -        | FC =  | 0.64175  | -        | TNOM   | 300      | K        |


All parameters are ready to use, no scaling is necessary.

Extracted on behalf of SIEMENS Small Signal Semiconductors by:

Institut für Mobil-und Satellitenfunktechnik (IMST)

© 1996 SIEMENS AG


#### Package Equivalent Circuit:




For examples and ready to use parameters please contact your local Siemens distributor or sales office to obtain a Siemens CD-ROM or see Internet: <http://www.siemens.de/Semiconductor/products/35/35.htm>

### Total power dissipation $P_{tot} = f(T_A^*, T_S)$


\* Package mounted on epoxy



### Permissible Pulse Load $R_{thJS} = f(t_p)$




### Permissible Pulse Load $P_{totmax}/P_{totDC} = f(t_p)$




### Collector-base capacitance $C_{cb} = f(V_{CB})$

$V_{BE} = v_{be} = 0, f = 1\text{MHz}$



### Transition frequency $f_T = f(I_C)$


$V_{CE} = \text{Parameter}$



### Power Gain $G_{ma}, G_{ms} = f(I_C)$

$f = 0.9\text{GHz}$


$V_{CE} = \text{Parameter}$



### Power Gain $G_{ma}, G_{ms} = f(I_C)$


$f = 1.8\text{GHz}$

$V_{CE} = \text{Parameter}$




**Power Gain**  $G_{ma}, G_{ms} = f(V_{CE})$ : \_\_\_\_\_  
 $|S_{21}|^2 = f(V_{CE})$ : - - - - -

$f$  = Parameter




**Intermodulation Intercept Point**  $IP_3 = f(I_C)$   
 (3rd order, Output,  $Z_S = Z_L = 50\Omega$ )

$V_{CE}$  = Parameter,  $f = 900\text{MHz}$



**Power Gain**  $G_{ma}, G_{ms} = f(f)$

$V_{CE}$  = Parameter



**Power Gain**  $|S_{21}|^2 = f(f)$

$V_{CE}$  = Parameter

